

Emergency Override Switches

The main and slave override switches types HE 075, HE 076 and HE 080 according to DIN 12101/9 are the ideal user interface for smoke control systems, particularly stairwell and lobby ventilators. The HE 080 has got additionally a buzzer for acoustic warning.

The version of HE-080 includes a built-in buzzer for an acoustic signal in the case of alarm and fault. The mute button can reset it. Optionally the main control switch without buzzer is offered as HE-082 (replaces HE-075).

For the other triggering places you should use the off-site unit HE-081 (one LED: RWA-replaces HE-076) without buzzer.



Technical Data:

Electrical Emergency override switches Item number:		
Voltage:	24 V DC	
Max. Current:	10 mA	
Type of switch:	"Open" button (transfer contact) "Close" button (close contact) reset button (hidden)	
LED sign:	Red = alarm (open) Yellow = defect Green = ready	
Dimensions:	Plastic housing (surface) according to DIN 14655 / EN 12101/9 $125 \times 125 \times 35$ mm with side hinged door, including break glass pane and key. (Optional available in housing for in-wall mounting)	
Colours:	Orange (RAL 2011) according to VdS 2592 / EN 12101/9 Grey (RAL 7035) Yellow (RAL 1004) Blue (RAL 5009)	
Weight:	Approx. 0.25 kg	

Article

Main control switches type HE 082 The curcuit board is populated with 3 LED indicators.		
	Тур	Item number
	HE 082 Orange RAL 2011	A3 2150

PRODUCTINFORMATION



according to VdS guideline 2592	
HE 082 Yellow RAL 1004	A3 2151
HE 082 Blue RAL 5009	A3 2153
HE 082 Grey RAL 7035	A3 2152

Off site switches type HE 081 The curcuit board is populated with 1 LED indicator: red = alarm (open)		
	Тур	Item number
	HE 081 Orange RAL 2011	A3 2140
	according to VdS guideline 2592	
	HE 081 Yellow RAL 1004	A3 2141
	HE 081 Blue RAL 5009	A3 2143
	HE 081 Grev RAI 7035	A3 2142

Main control switches type HE-080 The curcuit board is populated with 3 LED indicators and a buzzer for acoustics warning. Item number HE 080 Orange RAL 2011 according to VdS guideline 2592 HE 080 Grey RAL 7035 A3 2131 HE 080 Yellow RAL 1004 A3 2132 HE 080 Blau RAL 5009 A3 2133

Curcuit boards for HE/FTZ

Accessories	Item number
HE 080	A3 10035

PRODUCTINFORMATION



board	
HE 081 board	A3 10045
HE 082 board	A3 10055

Housing for HE and FTZ

Plastic or aluminium incl. break glass pane and key

Accessories	Item number
HE 07X/-08X Orange RAL 2011 according to VdS guideline 2592 Plastic housing	A3 2005 A
HE 07X/-08X Yellow RAL 1004 Plastic housing	A3 2001 A
HE 07X/-08X Blue RAL 5009 Plastic housing	A3 2002 A
HE 07X/-08X Grey RAL 7035 Plastic housing	A3 2003 A
HE-UP-VA Unterputzgehäuse, Typ HE-UP-VA f.elektr. Handansteuereinrichtung, Typ HE**/DIN FTZ	A3 2106
HE/ALU-LG-Orange for HE-07X/-08X Aluminium-housing	A3 2042 A
HE/ALU-LG-Yellow for HE-07X/-08X Aluminium-housing	A3 2031 A
HE/ALU-LG-Blue for HE-07X/-08X Aluminium-housing	A3 2032 A
HE/ALU-LG-Grey for HE-07X/-08X Aluminium-housing	A3 2033 A

Spare key

Accessories	Item number
DINSCHL made of steel fitting for HE and FTZ	E 10019

Spare pans

Accessories	Item number
DINS 80 x 80 x 1 mm fitting for HE and FTZ	E 10014





DINS 80 x 80 x 1 mm fitting for HE and FTZ (20 Pieces)	E 10014
SCHEIBE/RUND fitting for FTZ/UP, D = 60 mm	E 10017