

Spring-return actuator for fire and smoke dampers 90° in ventilation and air-conditioning systems.

- Torque 18/12 Nm
- Nominal voltage AC/DC 24 V
- Control: Open/close
- Damper rotation: 12 mm form-fit



## Technical Data

<b>Electrical data</b>	Nominal voltage	AC 24 V, 50/60 Hz / DC 24 V		
	Nominal voltage range	AC 19.2 ... 28.8 V / DC 21.6 ... 28.8 V		
	Power consumption	motoring	7 W @ nominal torque	
		holding	2 W	
		for wire sizing	10 VA / I <sub>max</sub> . 8.3 A @ 5 ms	
	Auxiliary switch	2 x 1 SPDT		
Contact rating (contacts gold plate on silver)	1 mA ... 6 A (3 A), DC 5 V ... AC 250 V <input type="checkbox"/>			
Switching points	5° / 80°			
Connecting cable	motor	1 m, 2 x 0.75 mm <sup>2</sup> (halogen-free)		
	auxiliary switch	1 m, 6 x 0.75 mm <sup>2</sup> (halogen-free)		
<b>Functional data</b>	Torque	motor	Min. 18 Nm	
		spring-return	Min. 12 Nm	
	Direction of rotation	Selected by mounting L/R		
	Angle of rotation	Max. 95° (incl. 5° spring pretensioning)		
	Running time	motor	140 s	
		spring-return	~16 s (t <sub>amb</sub> = 20°C)	
	Sound power level	motor	Max. 45 dB (A)	
		spring-return	~62 dB (A)	
	Damper rotation	Form-fit 12 mm (10 with adapter supplied)		
	Position indication	Mechanical with pointer		
Service life	Min. 60'000 safe positions			
<b>Safety</b>	Protection class	III Safety extra-low voltage		
	Degree of protection	IP54 in all mounting positions		
	EMC	CE according to 89/336/EEC, 92/31/EEC, 93/68/EEC		
	Mode of operation	Type 1.AA.B (according to EN60730-1)		
	Rated impulse voltage	0.8 kV (according to EN60730-1)		
	Control pollution degree	3 (according to EN60730-1)		
	Ambient temperature range	normal duty	-30 ... +50°C	
		safety duty	The safe position will be attained up to max. 75°C when initiated by a thermal trip	
	Non-operating temperature	-40 ... +80°C		
	Ambient humidity range	According to EN 60730-1		
Maintenance	Maintenance-free			
<b>Dimensions / weight</b>	Dimensions	See «Dimensions» on page 2		
	Weight	Approx. 2'800 g		

## Safety notes



- The actuator is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- The actuator is adapted and mounted to the fire and smoke damper by the damper manufacturer. For this reason, the actuator is only supplied direct to safety damper manufacturers. The manufacturer then bears full responsibility for the proper functioning of the damper.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- The device contains electronic and electrical components and may not be disposed of with the household waste. Observe local regulations and valid laws.

## Product features

- Mode of operation** The actuator moves the damper to its normal working position while tensioning the return spring at the same time. If the power supply is interrupted, the energy stored in the spring moves the damper back to its safe position.
- Signalling** Two microswitches with fixed settings are installed in the actuator for indicating the damper end positions.  
The position of the damper blade can be read off on a mechanical position indicator.
- Manual operation** Without power supply, the damper can be operated manually and fixed in any required position. Release of the locking mechanism can be achieved manually or automatically by applying the supply voltage.

## Accessories


	Description	Type
<b>Electrical accessories</b>	Thermoelectric Tripping Device	BAE72 (-F-ST)
	Thermoelectric Tripping Device with test button	BAE72-S (-F-ST)
	Auxiliary switch, 1 x SPDT 6 A (2.5 A), AC 250 V	SN1
	Auxiliary switch, 2 x SPDT 6 A (2.5 A), AC 250 V	SN2
	Cable set with plug (L=0.5 m) for BF.. and BLF.. on BKN230-24	ZST-BS
<b>Mechanical accessories</b>	Adapter with clamp for rotary axes up to 20 mm for BF.. and BLF..	ZK-BF
	Adapter with DM18 rotary axis, L = 33 mm, for BF.. and BLF..	ZA18-BF
	Adapter 12/8 mm for BF.. and BLF..	ZA8-BF
	Adapter 12/11 mm for BF.. and BLF..	ZA11-BF
	Bracket for SN1 and SN2 auxiliary switches for BF..	ZSN-BF

## Electrical installation

### Wiring diagram

#### Note

- Supply via safety isolation transformer
- Parallel connection of several actuators possible. Power consumption must be observed!



## Dimensions [mm]

### Dimensional diagrams

