

2. LF-2_{-CD} Product Information Damper actuators with spring return





The complete range of damper actuators for general use in HVAC systems

Ţ	ype	LM	NM	SM	АМ	GM	LF	AF
				No CO		WE BE		
	Torque	4 Nm	8 Nm	15 Nm	18 Nm	30 Nm	4 Nm	15 Nm
Coring raturo	function	-	-	-	-	-	Ĵ	-©
Eor dampare	up to approx.	0.8 m²	1.5 m²	3 m²	3.6 m²	6 m²	0.8 m ²	3 m²

For more information, please contact your Belimo Representative or order any brochures you need by fax.

Fax to: BELIMO (address overleaf)

Please send us product brochures on the following damper actuators:

□ LM... □ NM... □ SM... □ AM... □ GM... □ AF... □ Electrical accessories

Please send also information on:

- □ Motorized fire and smoke dampers
- □ Variable air-volume control (VAV-Control)

□ Please call us back

Sender

Company:		
Name:		
Address:		
Post Code:	Country:	
Tel.:	Fax:	
E-Mail:	Date:	



Selection table

Torque	4 Nm		LF24	LF24-5	LF230	٢.٤٢	1.5 LF24-3	LF24.8	ŜĄ
Nominal voltage	AC 24 V			٠	•			•	•
	DC 24 V			•	•			•	•
	AC 230 V					•	•		
Running time	motor	4075 s		•	٠	•	٠		
	motor	150 s						•	•
	spring return	≈ 20 s		•	•	•	•	•	•
Control	Open/Close			•	٠	•	٠		
	3-point							•	
	modulating DC 0	10 V							•
Direction of rotation	on reversible (right/l	left)		٠	•	•	•	٠	•
Auxiliary switch p	otential-free (adjust	able)			•		•		
Mechanical angle	of rotation limiting			٠	•	•	٠	•	•
Continuous positi	on feedback								•
Damper rotation v	vith universal spind	le clamp		•	•	•	•	•	•

Actuators conforming to US standards on request.

Spring return actuators, Open/Close

4
4
5
5
6

Spring return actuator, 3-point

LF24-3	7
Examples of control modes LF24-3	8

Spring return actuator, modulating

F24-SR	
Control/monitoring functions LF24-SR	10

Mechanical accessories

Mounting accessories LF	11
General mounting accessories	12

Mounting instructions

Direct mounting	13
Mounting with linkage	14
Mounting for tight-sealing dampers	15

Note

Using BELIMO damper actuators

The actuators listed in this catalogue are intended for the operation of air dampers in HVAC systems.

Torque requirements


When calculating the torque required to operate dampers, it is essential to take into account all the data supplied by the damper manufacturer concerning cross sectional area, design, mounting and air flow conditions.

LF24, LF24-S Spring return actuators 4 Nm





Wiring diagram



Technical data	LF24, LF24-S			
Nominal voltage	AC 24 V 50/60 Hz, DC 24 V			
Nominal voltage range	AC 19.228.8 V, DC 21.628.8 V			
For wire sizing	7 VA (Imax 5.8 A @ 5 ms)			
Power consumption – motoring – holding	5 W 2.5 W			
Connecting cable	- motor 1 m long, 2 x 0.75 mm² - auxiliary switch (LF24-S) 1 m long, 3 x 0.75 mm²			
Auxiliary switch (LF24-S) – Switching point	1 x SPDT 6 (1.5) A, AC 250 V □ adjustable 0100% <⊄			
Direction of rotation	selected by mounting L/R			
Torque	 motor min. 4 Nm (at rated voltage) spring return min. 4 Nm 			
Angle of rotation	max. 95° (adjustable 37100%			
Running time	– motor 4075 s (04 Nm) – spring return ≈ 20 s @ -2050 °C / max. 60 s @ -30 °C			
Sound power level	motor max. 50 dB (A), spring \approx 62 dB (A)			
Service life	min. 60 000 operations			
Position indication	mechanical			
Protection class	(safety extra-low voltage)			
Degree of protection	IP 54			
Ambient temp. range Non-operating temp. Humidity test	−30+50 °C −40+80 °C to EN 60335-1			
EMC Low Voltage Directive	CE according to 89/336/EEC, 92/31/EEC, 93/68/EEC CE according to 73/23/EEC			
Maintenance	maintenance-free			
Weight	1400 g			

Dampers up to approx. 0.8 m²

Open/Close actuator (AC/DC 24 V)

Control by single-pole contact

Application

For the operation of air dampers that perform safety functions (e.g. frost and smoke protection, hygiene, etc.).

Mode of operation

The LF... actuator moves the damper to its normal working position while tensioning the return spring at the same time. If the power supply is interrupted, the energy stored in the spring moves the damper back to its safe position.

Product features

Simple direct mounting on the damper spindle by universal spindle clamp. An antirotation device is supplied to prevent unwanted rotation of the whole unit.

Mechanical angle of rotation limiting adjustable with built-in stop.

High functional reliability

w0108712

The actuator is overload proof, needs no limit switches and halts automatically at the end stop.


Flexible signalling 0...100% *⊲*, with adjustable auxiliary switch (LF24-S only).

Adjusting the auxiliary switch LF24-S, page 6

Mounting accessories, page 11

Mounting instructions, pages 13...15


Important: Read the notes about the use and torque requirements of the damper actuators on page 3.







Wiring diagram



Technical data	LF230, LF230-S			
Nominal voltage	AC 230 V 50/60 Hz			
Nominal voltage range	AC 198264 V			
For wire sizing	7 VA (Imax 150 mA @ 10 ms)			
Power consumption – motoring – holding	5 W 3 W			
Connecting cable	- motor 1 m long, 2 x 0.75 mm² - auxiliary switch (LF230-S) 1 m long, 3 x 0.75 mm²			
Auxiliary switch (LF230-S) – Switching point	1 x SPDT 6 (1.5) A, AC 250 V □ adjustable 0100% <			
Direction of rotation	selected by mounting L/R			
Torque	motormin. 4 Nm (at rated voltage)spring returnmin. 4 Nm			
Torque	max. 95° (adjustable 37100% < vith built-in mechanical stop)			
Running time	– motor 4075 s (04 Nm) – spring return ≈ 20 s @ −2050 °C / max. 60 s @ −30 °C			
Sound power level	motor max. 50 dB (A), spring \approx 62 dB (A)			
Service life	min. 60 000 operations			
Position indication	mechanical			
Protection class	II (all insulated)			
Degree of protection	IP 54			
Ambient temp. range-30+50 °CNon-operating temp40+80 °CHumidity testto EN 60335-1				
EMC CE according to 89/336/EEC, 92/31/EEC, 93/68/EEC CE according to 73/23/EEC				
Maintenance	maintenance-free			
Weight	1550 g			

Dampers up to approx. 0.8 m²

Open/Close actuator (AC 230 V)

Control by single-pole contact

Application

For the operation of air dampers that perform safety functions (e.g. frost and smoke protection, hygiene, etc.).

Mode of operation

The LF... actuator moves the damper to its normal working position while tensioning the return spring at the same time. If the power supply is interrupted, the energy stored in the spring moves the damper back to its safe position.

Product features

Simple direct mounting on the damper spindle by universal spindle clamp. An antirotation device is supplied to prevent unwanted rotation of the whole unit.

Mechanical angle of rotation limiting adjustable with built-in stop.

High functional reliability

The actuator is overload proof, needs no limit switches and halts automatically at the end stop.


Flexible signalling 0...100% *⊲*, with adjustable auxiliary switch (LF230-S only).

Adjusting the auxiliary switch LF230-S, page 6

Mounting accessories, page 11


Mounting instructions, pages 13...15

Important: Read the notes about the use and torque requirements of the damper actuators on page 3.





Mounting side R




Starting point: Actuator in safe position

Procedure

- Turn the knob of the auxiliary switch until the tip of the arrow is pointing to the required switching position (see left).
 Example: Switching point setting = .4 corresponds to 40% angle of rotation.
- When the actuator runs to the operating position (ccw), the switch knob will also rotate counter-clockwise (ccw) and the auxiliary switch will operate as the tip of the arrow passes the scale zero (S1–S3 linked).

Mounting side L



Starting point: Actuator in safe position


Procedure

- Turn the knob of the auxiliary switch until the tip of the arrow is pointing to the required switching position (see left).
 Example: Switching point setting = .4 corresponds to 40% angle of rotation.
- When the actuator runs to the operating position (cw), the switch knob will also rotate clockwise (cw) and the auxiliary switch will operate as the tip of the arrow passes the scale zero (S1–S3 linked).





Wiring diagram



Technical data	LF24-3		
Nominal voltage	AC 24 V 50/60 Hz, DC 24 V		
Nominal voltage range	AC 19.228.8 V, [DC 21.628.8 V	
For wire sizing	5 VA (Imax 5.8 A @	2 5 ms)	
Power consumption – motoring – holding	2.5 W 1 W		
Connecting cable	1 m long, 4 x 0.75	mm²	
Input resistance Control inputs Y1, Y2 Direction of rotation	1000 Ω (0.6 W) – motor	selected with switch L/R	
	 spring return 	selected by L/R mounting	
Torque	– motor – spring return	min. 4 Nm (at rated voltage) min. 4 Nm	
Angle of rotation max. 95° (adjustable 37100% < with built-i mechanical stop)			
Running time	– motor 150 s – spring return ≈ 2	0 s @ −2050 °C / max. 60 s @ −30 °C	
Sound power level	motor max. 30 dB (A), spring \approx 62 dB (A)		
Service life	min. 60 000 operations		
Position indication	mechanical		
Protection class	(safety extra-low voltage)		
Degree of protection	IP 54		
Ambient temp. range Non-operating temp. Humidity test	–30+50 °C –40+80 °C to EN 60335-1		
EMC	CE according to 8	9/336/EEC, 92/31/EEC, 93/68/EEC	
Maintenance	maintenance-free		
Weight 1400 g			

Dampers up to approx. 0.8 m²

Modulating actuator (AC/DC 24 V)

3-point control

Application

For the operation of air dampers that perform safety functions (e.g. frost and smoke protection, hygiene, etc.).

Mode of operation

The LF24-3 is controlled by a 3-point signal. The actuator runs to the position specified by the control signal while tensioning the return spring at the same time. If the power supply is interrupted, the energy stored in the spring moves the damper back to its safe position.

Product features

Simple direct mounting on the damper spindle by universal spindle clamp. An antirotation device is supplied to prevent unwanted rotation of the whole unit.

Mechanical angle of rotation limiting adjustable with built-in stop.

High functional reliability


The actuator is overload proof, needs no limit switches and halts automatically at the end stop.

Examples of control modes, page 8

Mounting accessories, page 11


Mounting instructions, pages 13...15

Important: Read the notes about the use and torque requirements of the damper actuators on page 3.







Open/Close mode with single-wire control




3-point control by switch



3-point control by controller with triac outputs (reference potential \sim AC 24 V)




3-point control by controller with triac outputs (reference potential L AC 24 V)







Wiring diagram



Technical data	LF24-SR			
Nominal voltage	AC 24 V 50/60 Hz, DC 24 V			
Nominal voltage range	AC 19.228.8 V, I	AC 19.228.8 V, DC 21.628.8 V		
For wire sizing	5 VA (Imax 5.8 A @	@ 5 ms)		
Power consumption	2.5 W motoring, 1	W at rest		
Connecting cable	1 m long, 4 x 0.75	5 mm²		
Control signal Y	DC 010 V @ 100) k Ω input resistance		
Operating range	DC 210 V for 0	100%⊄		
Measuring voltage U	DC 210 V (max.	0.7 mA) for 0100% ⊄		
Direction of rotation	– motor – spring return	selected with switch L/R selected by L/R mounting		
Torque	– motor – spring return	min. 4 Nm (at rated voltage) min. 4 Nm		
Angle of rotation	max. 95° (adjustable 37100%			
Running time	– motor 150 s – spring return ≈	20 s @ -2050 °C / max. 60 s @ -30 °C		
Sound power level	motor max. 30 dB (A), spring ≈ 62 dB (A)			
Service life	min. 60 000 opera	ations		
Position indication	mechanical			
Protection class	(safety extra-low voltage)			
Degree of protection	IP 54			
Ambient temp. range-30+50 °CNon-operating temp40+80 °CHumidity testto EN 60335-1				
EMC	CE according to 8	39/336/EEC, 92/31/EEC, 93/68/EEC		
Maintenance	maintenance-free			
Weight	1400 g			

Dampers up to approx. 0.8 m²

Modulating actuator (AC/DC 24 V)

Control DC 0...10 V and position feedback DC 2...10 V

Application

For the operation of air dampers that perform safety functions (e.g. frost and smoke protection, hygiene, etc.).

Mode of operation

The LF24-SR is controlled by a standard DC 0...10 V signal. The actuator runs to the position specified by the control signal while tensioning the return spring at the same time. If the power supply is interrupted, the energy stored in the spring moves the damper back to its safe position.

Product features

Simple direct mounting on the damper spindle by universal spindle clamp. An antirotation device is supplied to prevent unwanted rotation of the whole unit.

Mechanical angle of rotation limiting adjustable with built-in stop.

High functional reliability

The actuator is overload proof, needs no limit switches and halts automatically at the end stop.


Electrical accessories (see Doc. 2. Z-1) SG..24 Positioners ZAD24 Digital position indicator

Control/monitoring functions, page 10

Mounting accessories, page 11

Mounting instructions, pages 13...15

Important: Read the notes about the use and torque requirements of the damper actuators on page 3.




Control and monitoring functions LF24-SR




Remote control 0...100%

Minimum position




Override control




Control by 4...20 mA via external resistor

Position indication and / or master-slave control (depending on position)



Function monitoring





K6-1




KH-LF (Application example see page 14)




ZDB-LF (Application example see page 13)



ZG-LF1 (Application example see page 14, fig. 1)



ZG-LF3 (Application example see page 14, fig. 2)



Mounting accessories LF...

K6-1

Spindle clamp Suitable for damper spindles 16...20 mm diameter.

ulameter.




The spindle clamp is secured to the actuator by means of a circlip.

KH-LF

diameter.

Crank arm with slot width 8.2 mm Suitable for damper spindles 8...16 mm

8...16



The crank arm is secured to the actuator by means of a circlip.

KH-LF1

Crank arm with slot width 8.2 mm Suitable for damper spindles 16...20 mm diameter.



The crank arm is secured to the actuator by means of a circlip.

ZDB-LF Angle of rotation limiting and pointer

The pointer is secured to the actuator by means of a circlip.


ZG-LF1 Damper linkage kit for flat mounting (with 2 ball joints KG8)

ZG-LF2 Damper linkage kit for flat mounting (without ball joints KG8)

ZG-LF3 Damper linkage kit for side mounting (with 2 ball joints KG8)








KH8

Universal crank arm Zinc-plated steel; suitable for damper spindles Ø 10...18 mm or □ 10...14 mm, slot width 8.2 mm.

KG8

Ball joint Zinc-plated steel; suitable for use with KH8 universal crank arms and round steel rod \emptyset 8 mm.






KG10

KG8






KG10 Ball joint

Zinc-plated steel; suitable for use with KH8 universal crank arm and round steel rod Ø 10 mm.







AV10-18 Universal spindle extension


Suitable for damper spindles 10...18 mm diameter.



If an AV10-18 is to be used in conjunction with an LF..., the actuator must be fitted with a K6-1 spindle clamp.




Instructions for direct mounting









Flat mounting (fig. 1)

- Kit specification ZG-LF1
- ① 1 mounting bracket LF

- (5) 2 ball joints KG8

3 screws M6 x 67 3 self-tapping screws 4.2 x 13

6 Universal crank arm: order separately, not included with the ZG-LF... mounting accessory.

Side mounting (fig. 2)

Kit specification ZG-LF3


- 2 2 mounting brackets LF

- (5) 2 ball joints KG8

2 screws M6 x 67

4 self-tapping screws 4.2 x 13





Installation steps as example

- 1. Move damper blades to the fail-safe position (a) and determine the orientation of the universal clamp.
- 2. Engage the actuator on the shaft as close as possible to the determined orientation. Fix the screws lightly on the V-bracket by hand. In the example the spring return has to go clockwise (cw). Therefore the actuator has to be visible with the mounting side **R**.
- **3.** Mount the universal mounting bracket in the right position (do not tighten the screws).
- **4.** Remove the screw at one end of the mounting bracket and pivot it away from the actuator (b).
- Loosen the universal clamp and, making sure not to move the damper shaft, rotate the actuator approximatively 5° in the direction which would open the damper (c).
- 6. Tighten the universal clamp to the shaft (10 mm wrench).
- Rotate the actuator "damper closed" to apply pressure to the damper seals (d).
- 8. Rotate the mounting bracket in the definitive position (e) and tighten all fasteners.